
Meridian 1

ISDN Primary Rate Interface

Maintenance

Document Number: 553-2901-500

Document Release: Standard 11.00

Date: October 1997

© 1989, 1997

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at this own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

October 1997

Standard, Release 11.00, X11 Release 23.

August 1996

Standard, Release 10.00, X11 Release 22.

December 1995

Standard, Release 9.00, X11 Release 21B.

April 1995

Standard, Release 8.00, X11 Release 21A.

December 1994

Standard, Release 7.00, X11 Release 20.

August 1, 1993

Standard, Release 6.00, X11 Release 19.

April 1, 1993

Standard, Release 5.00, up-issued for X11 Release 18.

December 31, 1992

Standard, Release 4.00, X11 Release 18.

December 1, 1991

Standard, Release 3.00, X11 Release 17.

December 20, 1990

Standard, Release 2.00, X11 Release 16.

***Note:** The traffic reports have been removed; see *Traffic measurement formats and output* (553-2001-450).*

vi of xiv

December 20, 1989

Standard, Release 1.00, X11 Release 15.

Contents

Introduction	1
References	2
PRI operations guide	3
PRI quick reference	4
PRI commands (LD 60)	5
PRI alarm commands	8
PRI test commands	10
PRI messages	10
DCHI quick reference	12
MSDL quick reference	13
D-channel commands (X11 release 17 and earlier)	15
D-channel commands (X11 release 18 and later)	16
MSDL commands (X11 release 18 and later)	17
D-channel messages	17
Maintenance service messages	17
Service message function	19
D-channel establishment	19
D-channel sanity polling	19
B-channel or ISL channel status change	19
Channel status audit	19
Service message commands	20
PRI status check	21
PRI start-up	24

Network Call Trace	26
Enhanced Trace command output	26
Configuring Network Call Trace	27
Tracing a call	28
Trace function 01	28
Example 1: Successful call with trace function 01	30
Example 2: Unsuccessful call with trace function 01	32
Trace function 02	33
Feature requirements	34
PRI fault clearing	35
PRI red alarm (local alarm)	35
Channel restoration	36
PRI yellow alarm (remote alarm)	37
Channel restoration	37
PRI problems	39
D-channel problems	41
PRI local loopback test	42
PRI self-test	43
PRI automatic loop test	43
Link diagnostic and remote loopback tests	44
Link diagnostic test	44
Remote loopback test	44
Coordinating the tests	44
PRI commands (LD 60)	46
PRI midnight routines	46
PRI messages	47
PRI error detection	47
Yellow alarm (remote alarm)	47
Bit error rate	48
Bipolar violation (BPV) tracking	48
Cyclic redundancy check (CRC)	49
Bit error rate thresholds	50
Frame slip	51
Frame alignment	54
TN to channel number conversion	55

Using the error counter	57
Replacing the PRI	59
D-channel maintenance	61
DCH tests 100 and 101 (QPC757 DCHI card only)	62
DCH tests 200 and 201 (QPC757 DCHI card only)	64
MSDL local loopback test (NT6D80)	66
MSDL remote loopback tests (NT6D80)	69
Protocol Log (PLOG)	72
Replacing the DCHI or MSDL	77
Clock Controller maintenance	79
Tracking mode	79
Free run (non-tracking) mode	79
Reference clock errors	79
Automatic clock recovery	81
Automatic clock switching	81
QPC471, QPC775 Clock Controller Card	82
Clock Controller switch settings	82
Replacing a Clock Controller card	83
Removing equipment	84
Installing equipment	84
ISDN Signaling Link maintenance	87
ISL interfaces	87
ISL status formats	90
Print programs (LD 20-22)	91
ISL start-up	92
Dedicated D-channel using DTI or PRI	92
ISL recovery	93
Digital Trunk/Primary Rate Interface (LD 60)	95
DTI and PRI commands	96

Clock Controller commands	97
D-channel diagnostic (LD 96)	99
Monitoring	99
D-channels	100
B-channels and ISL channels	101
ISDN features	102
Message types	103
Setting output format levels	104
Deactivate monitor from a maintenance telephone	106
Get monitor status	107
D-channel command summary	108
Multi-purpose Serial Data Link (MSDL) commands	109
MSDL D-channel command summary	109
Alphabetical list of commands	110
DCH messages	113
DTA messages	121
DTC messages	127
DTI messages	129
MSDL messages	133
PRI messages	139
Index	153